



320 W. Larch Rd. #16
Tracy, CA 95304
(209) 832-8890
centralvalleypartyrentals.com
facebook.com/centralvalleyparty

Hot Dog Steamer

Instructions

1. Ensure the machine is on a level surface.
2. Remove the hot dog basket and juice tray and add approximately 10qts of water (no more) into the heating compartment so that the water level is above the heating element. Using already hot water will reduce the heating time.
3. Place the tray and partition into the unit and put the wire compartments into place.
4. Place the hot dogs into the small compartment and the buns in the wire rack in the large compartment. Arrange the hot dogs and buns so that there is free circulation of steam.
5. Turn the switch to the "ON" position and set the thermostat control on "HIGH" until steam is generated.
6. For normal operation, set the thermostat control in the center of the range between "LOW" and "HIGH".
7. The steaming compartments have been designed to deliver the proper amount of steam in each compartment. No adjustments are necessary.
8. Keep the lids closed while not serving.
9. Add more water as necessary to maintain the water level. (Add hot water if possible).
10. When finished, allow water to cool and then drain the water from the drainpipe.

THIS MACHINE IS NOT TO BE RUN ON A GENERATOR

DO NOT IMMERSE THE MACHINE IN WATER